Model CS-32

TO START

Pull out the tape → Press "**Reset**" → Select pet with "**A**" → Press "**D**" twice → → Set to correct time → Press "**C**" twice → Press "**D**" → Pet born in 2 mins. ⇒ Pet mode. (**Dog** , **Cat** , **Dinosaur** , **Chicken** , **Panda** , **Frog** , **Penguin**)

FUNCTION KEY

- "**A**" Choice : use "**A**" to select icon indicated by cursor Δ.
  Clock mode : use "**A**" to move between clock ↔ alarm.
- "**B**" Status : Hold key to check age, weight, hunger, happiness, sleep and degree of education
- "**C**" Cancel : Pet mode, cancel the cursor Δ, Clock mode, alarm on/off.
- "**D**" Decide : Pet mode, enter icon use "**A**". If no icon go to clock mode. At clock mode go to pet mode.

ICON

- (Feeding)
  1 dinner = 1 status
  More than 12 snaks/Less than 5 drinks it becomes sick.
- (Dodge game)
  You have three chances win = 1 ♥ status
- (Medical injection)
  "" = sick and needs injection.
- (Education)
  When pet refuses to do what you want; select this icon and status increase.
- (Guess game)
  "**A**" select bigger than 7. "**B**" select smaller than 7; win = 1 ♥ status.
- (Weather)
  Wear a hat when sunny, carry an umbrella when it rain.
- (Cleaning)
  " " = dirty need to clean.

(Status)

Check status same as "**B**" button.

- (Day/Night)
  About 9:00 PM bed time, about 8:00 AM wake up. Also can control by yourself.

(Call)

When the pet need to nurse, the cursor Δ come out at the right down corner.

OTHER FUNCTION

- If "**Bye**" or angle shows up, press "**A**" "**C**" at the same time to re-start the game; at normal mode turn sound on/off (the alarm clock is still in use).
  Hold "**A**" and "**D**" 5 second to on/off pause mode, to pause or to continue the pet game. At pause mode no cursor will appear by "**A**". Time still function.
- Under normal mode, press "**A**" "**C**" and "**D**" hold on for 5 seconds to enter HISTOR Display. (500 days raising picture may be checked)



A. Switch to the next content
C. Enter pet changing picture (Right picture)
D. Quit (back to normal)

Age of raising
Pet name
How many times



A. The picture for next Year age.
C. The picture for precious year age.
D. Quit.



Nicht fur Kinder unter 36 Monaten geeignet, enthalt Kleinteile
Not for children below 36 months because of small parts
Buiten bereik houden van kleine kindern, met kleine conderdelen
Ne pas donner aux enfants au dessous de 36 mois.
a cause des petits parts

Battery : AG13 (LR 44) 2 pcs

MADE IN CHINA
1997